TOSHIBA

FILE NO. 023-200224

SERVICE MANUAL

COLOR TELEVISION

N2NSP Chassis

53AX62, 61A62

(TAC0279) *(TAC0278)*

– SUMMARY –

53AX62, 61A62 are the same as 50A61 except for the parts tabled on back of this sheet.
Use this service manual together with the service manual of 50A61, 50A11, 61A61 (File No. 020-200111).

PUBLISHED IN JAPAN, Aug., 2002 (So)

REPLACEMENT PARTS LIST DIFFERENCES

Location No.	Part No.	Description
A001	23411584	Wood Cabinet (53AX62)
A001	23411634	Wood Cabinet (61A62)
A101	23411583	Wood Cabinet (53AX62)
A101	23411633	Wood Cabinet (61A62)
A102	23527210	Speaker Grille (53AX62)
A102	23527149	Speaker Grille (61A62)
A150	23411581	Light Box (53AX62)
A150	23411632	Light Box (61A62)
A201	23540736	Bezel (53AX62)
A201	23540424	Bezel (61A62)
A202	23450421	Control Panel (53AX62)
A202	23450394	Panel (61A62)
A212	23450422	Control Panel (53AX62)
A213	23427995	Door (53AX62)
A224	23445542	Button (53AX62)
A401	23086947	COM Back (61A62)
A424	23540472	Back Board (61A62)
A701	23064541	Carton (53AX62)
A701	23064271	Carton (61A62)
A703	23946070	Packing, Top (53AX62)
A703	23946072	Packing, Top (61A62)
A708	23946071	Packing, Bottom (53AX62)
A708	23946073	Packing, Bottom (61A62)
C530	24109561	Chip, 560pF, ±10% (53AX62)
C904	24436681	CD, 680pF (53AX62)
C914	24436821	CD, 820pF(53AX62)
C926	24436821	CD, 820pF(53AX62)
K111	23405006	DELTA250A/B (53AX62)
K111	23430160	Delta, 79-A/B (61A62)
K112	23405006	DELTA250A/B (53AX62)
K113	23405006	DELTA250A/B (53AX62)
K113	23430160	Delta, 79-A/B (61A62)
K501	23311899	Lenti Sheet, SCREEN53KL-L (53AX62)
K501	23311952	Lenti Sheet, SCREEN61KM-L (61A62)
K502	23311892	Fresnel Sheet, SCREEN53KL-F (53AX62)

Location No.	Part No.	Description
K502	23837539	Fresnel Sheet, SCREEN61KH-F (61A62)
K503	23311859	Screen Protector, SCR-PRO53AL (53AX62)
K503	23311972	Screen Protector, SCR-PRO61KM (61A62)
K511	23311918	SCREEN53KL (53AX62)
K511	23311914	SCREEN61DL (61A62)
K601	23405040	Mirror (53AX62)
K601	23430528	MIRROR61H (61A62)
K912	23306370	Remote Hand Unit, CT-90047 (53AX62)
R7808	24872223	Chip, 22k ohm, 1/16W (61A62)
R7809	24872153	Chip, 15k ohm, 1/16W (61A62)
✻U701	23784777	DIGI-CONV Board, PB9453B (53AX62)
✻U701	23784779	DIGI-CONV Board, PB9453C (61A62)
✻U901	23786778	SIGNAL/CONV Board, PD0175E (53AX62)
✻U901	23786614	SIGNAL/CONV Board, PD0175B (61A62)
✻UA01	23708523	CRT-D Board, PD0178D (53AX62)
UY01	23148736	Module, MKMU31 (53AX62)
UZ01	23148747	Module, MYCJ32 (53AX62)
⚠V901R	23086771	Protector Coupling R (53AX62)
⚠V901R	23086788	Protector Coupling R (61A62)
⚠V902G	23086772	Protector Coupling G (53AX62)
⚠V902G	23086789	Protector Coupling G (61A62)
⚠V903B	23086773	Protector Coupling B (53AX62)
⚠V903B	23086790	Protector Coupling B (61A62)
Y101	23565715	Owner's Manual, English/French, 53AX62
Y101	23565704	Owner's Manual, English/French, 61A62

TOSHIBA CORPORATION

1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001, JAPAN